SAMSUNG

USER'S MANUAL

ENGLISH

ESPAÑOL

Indoor Unit	Outdoor Unit
DC18BTSA	DC18BTSX
DC24BTSA	DC24BTSX
DC30BTSA	DC30BTSX
DC36BTSA	DC36BTSX
DC42BTSA	DC42BTSX
DC48BTSA	DC48BTSX
DC48FTSA	DC48FTSX
DC60FTSA	DC60FTSX
DC60HTSA	DC60HTSX

System Air Conditioner



ⒺⓈⒶ DB98-29322A(1)

Safety Precautions

The following safety precautions must be taken when using your air conditioner.

WARNING

• Risk of electric shock Can cause injury or death. • Disconnect all remote electric power supplies before servicing, installing or cleaning.
• This must be done by the manufacturer or its service agent or a similar qualified person in order to avoid a hazard.

DURING OPERATION

- Users of this product are cautioned not to attempt repair of this product at their own discretion. Instead, they are requested to directly contact a designated service center or the outlet at which the product was purchased.
- Never spill any kind of liquid into the unit. Should this happen, unplug or main switch off the unit and contact an authorized service center.
- Do not insert anything between the air outlet blades because the inner fan may be damaged and could cause injury. Keep children away from the unit.
- Do not place any obstacles in front of the unit.
- Do not spray liquid of any kind into the indoor unit. Should this happen, switch off the breaker used for your air conditioner and contact your installation specialist.
- Make sure that the unit is correctly ventilated at all times:

  Do not place clothing or other materials over it.
- If the wireless remote control will not be used for a long time, remove the batteries. (If applicable)
- When using a wireless remote control, the distance should not be more than 7 meters from the air conditioner. (If applicable)

DISPOSING OF THE UNIT

- Before throwing out the device, it is necessary to pull back the battery cells and get rid of them safely for recycling reasons.
- When you need to dispose of the unit, consult your dealer. If pipes are removed incorrectly, refrigerant may blow out and come into contact with your skin, causing injury. Releasing refrigerant into the atmosphere also damages the environments.
- Please recycle or dispose of the packaging material for this product in an environmentally responsible manner.

OTHERS

- Never store or ship the air conditioner upside down or sideways to avoid damage to the compressor.
- The appliance is not intended for use by young children or infirm persons without supervision: Young children should be supervised to ensure that they do not play with the appliance.
- Max current is measured according to IEC standard for safety and current is measured according to ISO standard for energy efficiency.

Contents

◆ ***PREPARING YOUR AIR CONDITIONER***
- Safety Precautions..... 2
- View of the Unit 4
- Wireless Remote Controller-Buttons and Display 6
- The Receiver & Display Unit 7
- Wired Remote Controller-Buttons and Display..... 8

◆ ***RECOMMENDATIONS FOR USE***
- Operating Recommendations..... 9
- Temperature and Humidity Ranges..... 10
- Cleaning Your Air Conditioner 11
- Solving Common Problems..... 12

◆ ***TECHNICAL SPECIFICATIONS***

The feature of product

◆ Easier Installation : Slim Size
◆ Easier Tuning : Using Phase Control Motor
◆ Various useful Functions
◆ Convenient Control Functions

View of the Unit

The figures are shown in this instruction may differ from yours depending on the model.

Indoor Unit *DC18/24/30BTS✶✶*



Indoor Unit *DC36/42/48BTS/48FTS✶✶*



Indoor Unit *DC60FTS/DC60HTS✶✶*



Outdoor Unit

DC18BTS✶✶



DC24BTS✶✶



DC30BTS✶✶



DC36/42BTS✶✶



DC48BTS/DC48FTS/DC60FTS/DC60HTS✶✶



◆ If the heat exchanger in the outdoor unit gets dusty, cooling efficiency may fall. So clean the heat exchanger with water when it becomes dirty. However, be careful when you wash the surface of the heat exchanger because it is very sharp.

Wireless Remote Controller-Buttons and Display

The wireless remote controller is an optional accessory.
To use the wireless remote controller, refer to an appropriate manual.



Note

- After cleaning the air filter, press the Filter Reset button.
- Duct type air conditioner does not have function of adjusting air flow direction. Therefore, the function is not operated even if you press the button.
- The heat mode(☼) is not selected in cooling only models.

The Receiver & Display Unit

The Receiver & Display unit is an optional accessory and it is installed on the wall.
To use the receiver & display unit, refer to an appropriate manual.

Concealed Type



Standard Type



Wired Remote Controller-Buttons and Display

To use the wired remote controller, refer to an appropriate manual.



Note

- ◆ After cleaning the filter, press the "Filter Reset" button.
  The "Filter" sign will display when it's time to clean the filter, and will disappear if the "Filter Reset" button is pressed.
- ◆ The error code will appear in the on/off timer display when there's an error in the indoor unit or the outdoor unit. Please call the installer if an error code appears.

Operating Recommendations

Here are a few recommendations that you should follow when operating your air conditioner.

Topic	Recommendation
Power failure	If a power failure occurs while the air conditioner is operating, the unit will be switched off. When the power returns, the air conditioner starts up again automatically.

Temperature and Humidity Ranges

The following table indicates the temperature and humidity ranges, within which the air conditioner can be used.

If the air conditioner is used at...	Then...
High temperature	The automatic protection feature may be triggered and the air conditioner stopped.
Low temperature	A water leakage or some other malfunction may happen if the heat exchanger freezes.
High humidity levels	Water may condense on and drip from the surface of the indoor unit if it is used for a long periods.

Mode	Outdoor Temperature	Indoor Temperature	Indoor Humidity
Cooling	21°C to 54°C approx.	21°C to 32°C approx.	80% or less
Drying	21°C to 54°C approx.	21°C to 32°C approx.	-

✵ ***If the cooling operation is used at over 32°C(indoor temperature), it does not cool at its full capacity.***

Cleaning Your Air Conditioner

For the best use of your air conditioner, you must clean it every 2 weeks regularly to remove the dust that accumulates on the air filter.

IMPORTANT Before cleaning your air conditioner, ensure that you have switched off the electric circuit breaker used for the unit.

1 Pull the air filter to the right or left as you want.



2 Pull out the air filter.

3 Remove all dust on air filter with a vacuum cleaner or a brush. In case of serious dust accumulation, put the air filter in warm detergent water and shake it vertically.



4 Dry the air filter.

5 When you have finished, insert the filter into the unit.

Note

- After cleaning the air conditioner, press the Filter Reset button.
- Do not operate the air conditioner without the filter.



Solving Common Problems

Before contacting the after-sales service, perform the following simple checks. They may save your time and expense of an unnecessary call.

Problem	Explanation/Solution
The air conditioner does not operate at all	◆ Check that the breaker used for the air conditioner is switched on.
Wired Remote Controller	
When turning on/off the air conditioner, it is not turned on/off immediately.	◆ In case of using the wired remote controller for a group, the air conditioners connected to the remote controller are turned on/off in order. Thus, it takes some time(up to 32 seconds).
Wireless Remote Controller	
The air conditioner does not operate with the remote controller	◆ Check that there are no obstacles between you and the remote control sensor. ◆ Check the wireless remote controller batteries . ◆ Check that you are close enough to the remote control sensor. (7 metres/yards or less).
Wireless Remote Controller	
No beep is heard when you press (On/Off) on the remote controller	◆ Check that you are pointing the remote controller at the remote control sensor on the receiver & display unit. ◆ Replace the remote controller batteries if necessary. ◆ If there is a strong light around the air conditioner, a three-wavelength light, a neon sign, etc., for example, the air conditioner may not be operated with a remote controller. If this happens, use the remote controller close by the remote control sensor.
The air conditioner does not cool	◆ Check that the correct operating mode has been selected. ◆ The room temperature may be too low or too high. ◆ Dust may be blocking the air filter guard; refer to page 11 for cleaning instructions. ◆ Check that there is no obstacle in front of the outdoor unit.

Technical Specifications & Technology words

■ Technical Specifications

Model	Power Supply
DC18BTSA DC24BTSA DC30BTSA DC36BTSA DC42BTSA DC48BTSA	1Ø, 220V~, 60Hz
DC48FTSA DC60FTSA	3Ø, 220V~, 60Hz
DC60HTSA	3Ø, 380V~, 60Hz

■ The abbreviated technology words & the definition of technology terms

abbreviated technology words	definition of technology terms
COMP (Full name： compressor)	One that compresses, especially a machine used to compress gases.
BLOWER	One that blows, especially a mechanical device, such as a fan, that produces a current of air.
FAN	A device for creating a current of air or a breeze.
ASSY CONTROL BOX （ Full name : assemble control box ）	A restraining device of air-condition, measure, or limit.
MOTOR	Something, such as a machine or an engine, that produces or imparts motion.
ASSY EVAP / ASSY COND (Full name : assemble evaporator / assemble condenser)	Heat exchanger; A device, used to transfer heat from a fluid on one side of a barrier to a fluid on the other side without bringing the fluids into direct contact.

SAMSUNG ELECTRONICS

Contact SAMSUNG WORLD WIDE

If you have any comments or questions regarding a Samsung product, contact the SAMSUNG customer care center.

Country	Customer Care Center ☎	Web Site
TURKEY	444 77 11	www.samsung.com.tr
SOUTH AFRICA	0860 726 7864 (SAMSUNG)	www.samsung.com/za
U.A.E	800SAMSUNG (7267864)	www.samsung.com/mea
	8000-4726	

Ⓒ Samsung Electronics Co., Ltd. All Rights Reserved.